



DISH WASH LIQUID

ECODO DW - K1

It is an ecological, highly concentrated washing-up liquid for professional use. It easily removes all dried-on food residues and grease from all kitchenware, such as pots, pans, plates, cutlery, and kitchen utensils. It can also be used for washing surfaces and appliances in commercial kitchens and the food industry. This product is pH-neutral and produces a long-lasting, stable foam. It dries without streaking and rinses off easily.

INSTRUCTIONS FOR USE

It is manual dish wash liquid is a concentrated product. Take 20 ml of product and dilute it with 1 litre of water. Use this solution for dish washing. Post washing rinse the utensils and dry them completely.

CONTAINER

5 Ltr

SPECIFICATION

Appearance	Viscous Liquid
Colour	Honey
Odour	Citrus
PH value	5.5 - 6.5
Explosion limits	None
Oxidizing properties	None
Water solubility	Easily soluble in water

PRECAUTION

Keep locked up and place reach out of children. If swallowed, please seek medical advice immediately and show this container label.

NOTE

The above information is in good faith but without warranty. Refer to product Material Safety Data Sheet for specific health hazard, first aid and precautionary information.

